

Start

Blue/White

Run/Start

White or White/Orange

Key In

Yellow

Bat + F20 5 Amp

Green

Acc/Run

Not Used

NDT USED

Violet/Green

NDT USED

NDT USED

Yellow

Green

Blue

White 14

RED 14 Gα

RED 10 Gα

BROWN

SI 340 U

BLACK



- 1
- 2
- 3
- 4
- 5
- 6

Connect Brown wire to brake
 light CMHL violet/white (must use
 AUX relay see Dwg. No: 01-0088)

Secure Idle

Chassis Make

Ford

Year
2020

Title

Explorer

Size

A

DWG NO: 01-0705