

CHEVROLET INSTALLATION INSTRUCTIONS
GM Trucks 2007
PN: SI 340 TK 06

Secure-Idle, Inc.
210 W. Lincoln St.
Saybrook, IL 61770
Ph. 309.475.2286
Fax 309.475.2140
www.secure-idle.com

SECURE-IDLE is an ignition switch bypass device designed to provide all the electrical functions that the OEM ignition switch normally provides. For proper operation and long term performance, **DO NOT deviate from the wire connection instructions.**

For each wire connection, remove approximately one half inch of insulation from the OEM wire, but **DO NOT cut through the wire.** Cutting the wires causes high resistance and a possible failure point. Strip approximately one half inch of insulation from the end of the SECURE-IDLE wires to be attached to the OEM wires. Wrap the SECURE-IDLE wire around the bare area of the OEM wire and solder the connection. Tape the connection thoroughly after it cools.

DO NOT use scotch lock type pinch through connectors. These connectors cannot handle the higher amperages of the ignition circuits, and will void the SECURE-IDLE warranty.

Use the wiring diagram to locate the correct wire and pin location on the backside of this page.

Installation

1. Remove the lower dash panel under the steering column to access the OEM ignition switch which is mounted on the steering column. Mount the SECURE-IDLE unit near the ignition switch.
2. Locate a good metal ground and connect the **Black** SECURE-IDLE wire.
3. Locate the OEM ignition switch and wiring. Remove the insulation from the **PINK** wire, Pin 2, and attach the **RED** 18 Ga. SECURE-IDLE wire according to the above instructions. This OEM wire will be hot in **RUN**
4. Locate the **PINK/BROWN** wire, Pin 5. Attach the **WHITE** 18 Ga. SECURE-IDLE wire according to the instructions. This OEM wire will be hot in **ACC.** and **RUN.**
5. Locate the **BROWN** wire, Pin 3. Attach the **YELLOW** 18 Ga. SECURE-IDLE wire according to the instructions. This OEM wire will be hot in **START** and **RUN.**
6. Locate the **RED/WHITE** wire, Pin 4. Attach the **GRAY FUSIBLE LINK** wire according to the instructions. Connect the **RED** 10 Ga. wire to the **FUSIBLE LINK** by way of the quick disconnect connector. This OEM wire will be **HOT** at all times.
7. Connect the **BROWN** SECURE-IDLE wire to either of the following options:
 - 1: to back up Lamps, **LT GREEN** wire at the passenger side kick panel. (Do not use with flashing back up lights). This option is for automatic reset.
 - 2: to brake lights, **LIGHT BLUE /WHITE** (See #4 if brake light deactivation is required but the vehicle has flashing brake lights) This option is used for vehicle shutdown when the brake pedal is depressed
 - 3: to park brake switch wire, use this option where the park brake is requested for SECURE-IDLE activation and deactivation
 4. Use drawing 01-0080 For CMHL brake light activation if the vehicle has flashing brake lights or the emergency flasher is used.

TESTING THE SECURE-IDLE TK UNIT

1: With the shift lever in **PARK**

OPTION 1: Follow standard test procedure.

OPTION 2: For brake light deactivation. Follow standard procedures to test unit. When the vehicle is under secure Idle control, Depressing the brake pedal will automatically shut down the vehicle. Insert the key and turn to the run position, depress the brake pedal. This will reset the unit and put the vehicle back under OEM ignition control.

OPTION 3: Depress park brake pedal and then follow standard test procedures. To disengage SECURE-IDLE unit, insert the ignition key and turn to the **RUN** position, release the park brake. Vehicle will shut down if key is not in **RUN** position

Testing the SECURE-IDLE Unit

1. With the shift lever in **PARK** start the vehicle. Push and release the **RED** push button switch. This activates the SECURE-IDLE unit. You will hear a single click when the button is pushed.
2. Turn the key to the **OFF** position. The vehicle will remain running. Test all OEM electrical functions, ie: blower motor, power windows, radio, etc.
3. Turn the key to the **START** position, the starter motor should not crank.
4. Pull the shift lever from **PARK** into **DRIVE** then back into **PARK**. This resets the SECURE-IDLE unit. Turn the key to the **OFF** position.
5. Start the vehicle; activate the SECURE-IDLE unit by pushing and releasing the **RED** push button.
6. Turn the key to the **OFF** position and remove the key. The vehicle will remain running as it is now under SECURE-IDLE control, and the steering wheel and the gear shift lever are locked.
7. Recheck all **RUN** and **ACCESSORY** electrical functions while the vehicle is under SECURE-IDLE control.
8. With the brakes applied, insert the key and turn to the **ON** or **RUN** position. Move the gear shift lever from **PARK** to **DRIVE** then back to **PARK**. This resets the SECURE-IDLE unit and the vehicle is now back under OEM ignition switch control.
9. Turn the key to the **OFF** position and the engine will stop.
10. Tie wrap all loose wires and replace the removed panels.
11. To disable the SECURE-IDLE unit, pull apart the quick disconnect. It is located on the **RED** 10 Ga. wire coming out of the SECURE-IDLE unit.
12. Instruct all drivers on the proper operating, reset procedures, and the location of the quick disconnect of the SECURE-IDLE unit.
13. In the unlikely event that the engine will not turn off after the unit has been reset, the driver should disable the unit by pulling apart the quick disconnect.
14. If the engine stalls while under SECURE-IDLE control, the unit must be reset before the engine can be restarted.

Wiring Diagram for Chevrolet Trucks PN: SI 340 TK 06

Contact Information: Jim Hoffman, Engineer, at 260.517.9580

