

# FORD INSTALLATION INSTRUCTIONS

Explorer 2005

PN: SI 340 U

Secure-Idle, Inc.  
210 W. Lincoln St.  
Saybrook, IL 61770  
Ph. 309.475.2286  
Fax 309.475.2140  
www.secure-idle.com

SECURE-IDLE is an ignition switch bypass device designed to provide all the electrical functions that the OEM ignition switch normally provides. For proper operation and long term performance, **DO NOT deviate from the wire connection instructions.**

For each wire connection, remove approximately one half inch of insulation from the OEM wire, but **DO NOT cut through the wire.** Cutting the wires causes high resistance and a possible failure point. Strip approximately one half inch of insulation from the end of the SECURE-IDLE wires to be attached to the OEM wires. Wrap the SECURE-IDLE wire around the bare area of the OEM wire and solder the connection. Tape the connection thoroughly after it cools.

**DO NOT use scotch lock type pinch through connectors.** These connectors cannot handle the higher amperages of the ignition circuits, and will void the SECURE-IDLE warranty.

**Use the wiring diagram to locate the correct wire and pin location on the backside of this page.**

## Installation

1. Remove the lower dash panel under the steering column to access the OEM ignition switch which is mounted on the steering column. Mount the SECURE-IDLE unit near the ignition switch.
2. Locate a good metal ground and connect the **Black** SECURE-IDLE wire.
3. Locate the OEM ignition switch and wiring. Remove the insulation from the **RED/LT. GREEN** wire, Pin1, Circuit16, and attach the **RED** 14 Ga. SECURE IDLE wire according to the above instructions. This OEM wire will be hot in **START** and **RUN**.
4. Locate the **DARK GREEN/LT. GREEN** wire, Pin 6, Circuit 75. Attach the **WHITE** 14 Ga. SECURE-IDLE wire according to the instructions. This OEM wire will be hot in **ACC.** and **RUN**.
5. The **YELLOW** SECURE-IDLE Wire will not be used. Cap the end of this wire and secure it to the other wiring harness so that it does not hang down.
6. Locate the **YELLOW** wire, Pin 4, Circuit 37. Attach the **GRAY FUSIBLE LINK** wire according to the instructions. Connect the **RED** 10 Ga. wire to the **FUSIBLE LINK** by way of the quick disconnect connector. This OEM wire will be **hot** at all times.
7. Locate the **RED** wire, Pin 7, Circuit 50. Cut this wire into, being sure to leave enough room to strip back the ends and install Butt connectors. Strip back the ends of the OEM wires app. one quarter of an inch. Crimp on the **BLUE** 14/16 Ga. Butt connectors. Connect the **GREEN** SECURE-IDLE wire to the **RED** wire end which leads back into the wire harness. Connect the **BLUE** SECURE-IDLE wire to the **RED** wire end which leads to the ignition switch. This OEM wire will be hot in **START** only.
- 8 Connect the **BROWN** SECURE-IDLE wire to either of the following options.
  1. To Back Up Lamps, **BLACK/PINK** wire at the transmission Park/Neutral Switch. (Use print No. (01-0020) with flashing Back up Lights)
  2. To Park Brake Pedal Switch, **LT. GREEN/RED** wire.
  3. To a customer supplied SPST Switch, **BROWN** wire to Pin 1, customer supplied wire from Pin 2, to Ground.

## Testing the SECURE-IDLE U Universal Unit

1. With the shift lever in **PARK**
  - OPTION 1. Follow standard test procedure.
  - OPTION 2. Depress Park Brake Pedal and then follow standard test procedures. To disengage SECURE-IDLE unit, insert the ignition key and turn to the **RUN** position, release the Park Brake.
  - OPTION 3. Turn the SPST switch to the **ON** position and then follow standard test procedures. To disengage SECURE-IDLE unit, insert the ignition key and turn to the **RUN** position turn the SPST switch **OFF**.

## Testing the SECURE-IDLE Unit

1. With the shift lever in **PARK** turn the key to the **ON** or **RUN** position. Push and release the **Red** push button switch. This activates the SECURE-IDLE unit. You will hear a single click when the button is pushed.
2. Turn the key to the **OFF** position. Test all OEM electrical functions, ie: blower motor, power windows, radio, etc.
3. Turn the key to the **START** position, the starter motor should not crank.
4. Pull the shift lever from **PARK** into **DRIVE** and then back into **PARK**. This resets the SECURE-IDLE unit. Turn the key to the **OFF** position.
5. Start the vehicle; activate the SECURE-IDLE unit by pushing and releasing the **Red** push button.
6. Turn the key to the **OFF** position and remove the key. The vehicle will remain running as it is now under SECURE-IDLE control, and the steering wheel and gear shift lever is locked.
7. Recheck all **RUN** and **ACCESSORY** electrical functions while the vehicle is under SECURE-IDLE control.
8. With the brakes applied, insert the key and turn to the **ON** or **RUN** position. Move the gear shift lever from **PARK** to **DRIVE** then back to **PARK**. This resets the SECURE-IDLE unit and the vehicle is now back under OEM ignition switch control.
9. Turn the key to the **OFF** position and the engine will stop.
10. Tie wrap all loose wires and replace the removed panels.
11. To disable the SECURE-IDLE unit, pull apart the quick disconnect. It is located on the **RED** 10 Ga. wire coming out of the SECURE-IDLE unit.
12. Instruct all drivers on the proper operating, reset procedures, and the location of the quick disconnect of the SECURE-IDLE unit.
13. In the unlikely event that the engine will not turn off after the unit has been reset, the driver should disable the unit by pulling apart the quick disconnect.
14. If the engine stalls while under SECURE-IDLE control, the unit must be reset before the engine can be restarted.

### Wiring Diagram for Explorer PN: SI 340 U

Contact Information: Jim Hoffman, Engineer, at 260.517.9580

